THE
MANNER of FIXING
THE
CLEPSYDRA, or WATER-CLOCK,
AS MADE BY
ARNOLD FINCHETT,
At Number 148, Cheapside, London.

HANG the Clock upright againſt the Wall.

Hang the Water-Barrel on the Wire-Hooks underneath the Clock-Head, juſt free from the Wall.

Let the Line that goes over the Pulley be fixed by the Hook within the ſmall Button on the right-hand Side, and the Bucket that holds the Shot on the left.

A few Grains of Shot make the Clock go faſter or ſlower.

Take out Shot to make it go faſter; and, to make it go ſlower, put in Shot.

Once in ten Days, or a Fortnight, wipe the Strings and keep the Clock clean.

Put the Lamp to burn all Night, when very clean, and the Wick cut a Quarter of an Inch above the Top of the Pipe, into the Hole within the Door of the Lantern, to give Light to the Room, and ſhew the Hour.

E5 R